

**INSTALLATION INSTRUCTIONS**  
**1986-1996 C4 CORVETTE ACCENT TUBES**  
**590060**

**PLEASE READ INSTRUCTION THOROUGHLY BEFORE INSTALLING**

1. REMOVE COVER PANEL FROM CARGO BAY HATCH (9 NUTS). PICTURE A
2. WITH COVER OFF LAY IT UPSIDE DOWN ON BENCH OR A TABLE TO WORK ON IT EASIER.
3. USING A PLIERS REMOVE THE **2ND** AND **4TH** STUDS ON EACH SIDE BY SNAPPING THEM OFF CAREFULLY (SOME MAY ALREADY BE BROKEN OFF). PICTURE B.
4. REMOUNT COVER BACK ON CARGO HATCH USING ONLY THE **1<sup>ST</sup>**, **3<sup>ND</sup>** AND **CENTER** STUDS ON EACH SIDE.
5. DRILL A 5/16" HOLE IN THE EXISTING PLACES WHERE THE STUDS WERE REMOVED. (4) HOLES WILL BE DRILLED.
6. PLACE ACCENT TUBE ON TOP OF COVER AND MOUNT WITH 1/4" BOLT AND WASHER FROM THE UNDERSIDE UP THROUGH THE COVER INTO ACCENT TUBE. BOLTS & WASHERS PROVIDED.
7. TIGHTEN BOLTS. DO NOT OVER TIGHTEN. CLOSE CARGO LID.

**PARTS LIST**

	<b>QTY</b>	<b>PART NUMBER</b>	<b>ITEM DISCRIPTION</b>
1	2	560189	ACCENT TUBE,2.00,CHROMED
2	4	101370	WSHR-FL,SST,.281X.625
3	4	101381	SCR-HEX HD CAP,1/4-20 X 1.00

***LIVERNE***  
TRUCK  
EQUIPMENT  
INC.  
1200 Birch Street  
Brandon, SD 57005

560188 SHEET 1 20AUG08

PICTURE A



PICTURE B

